

TACTICAL BLITZ®

GENERAL RECOMMENDATIONS:

Seepage (1 - 5 bph losses):

Mix 10 - 15 ppb TACTICAL BLITZ® in the active mud in an available mixing/slugging tank. Pump 10 - 15 bbl sweeps every stand or as needed.

Moderate Seepage (5 - 25 bph losses):

Mix 25+ ppb TACTICAL BLITZ® in the active mud in an available mixing/slugging tank. Pump 15 - 30 bbl sweeps every stand or as needed.

Severe Seepage (25+ bph losses):

Mix 35 - 50 ppb TACTICAL BLITZ® in the active mud in an available mixing/slugging tank. Pump 25 - 40 bbl sweeps every stand or as needed.

No Returns (while pumping) WITH downhole tools:

1. Mix 80 - 100 bbls of 50 - 100 ppb TACTICAL BLITZ® in the active mud in an available mixing/slugging tank.
2. Spot full volume TACTICAL BLITZ® pill just above known loss zone. If the loss zone is unknown, spot the TACTICAL BLITZ® pill above the depth of initial losses.
3. Pull above the calculated top of pill or preferably back up into the last casing shoe.
4. Squeeze an initial volume, not to exceed half of pumped volume of TACTICAL BLITZ® pill.
5. Perform a gentle hesitation squeeze to achieve desired pressure.

No Returns WITHOUT downhole tools:

TOP-SQUEEZE™ is the preferred method for responding to total losses. **TOP-SQUEEZE™** is a dewatering pill that is mixed in a separate clean tank with fresh water. Call for a "real time" recommendation @ 1-888-783-0036.